# 用示波器观测动态磁滞回线

## 雷逸鸣

### 1 100Hz 下铁氧体饱和磁滞回线的测量结果

各元件参数取为:

$$R_1 = 2\Omega, R_2 = 50 \text{k}\Omega, C = 10.0 \mu\text{F}, f = 100 \text{Hz}$$

#### 1.1 测量数据


电路图及各物理量命名同教材图 30-3

表 1 磁滞回线数据

—————————————————————————————————————				
$u_{\rm x}/{\rm mV}$	u <sub>y</sub> /mV	H/(A/m)	B/T	
260	14.5	150	0.390	
119	12.7	68.7	0.341	
56	10.2	32.3	0.274	
17	7.20	9.81	0.194	
0	3.80	0.00	0.102	
-19	0.00	-11.0	0.000	
-46	-4.80	-26.5	-0.129	
-79	-9.10	-45.6	-0.245	
-139	-12.1	-80.2	-0.325	

绘成折线图如图 1 所示:

图 1 饱和磁滞回线



此时,饱和磁感应强度为:

$$B_s = \frac{R_2 C}{N_2 S} u_s = 0.390 T$$

剩余磁感应强度为:

$$B_r = \frac{R_2 C}{N_2 S} u_r = 0.102 T$$

矫顽力为:

$$H_C = \frac{N_1}{lR_1} u_C = 11.0 A/m$$

#### 1.2 其他频率下各量数值

#### 1.2.1 取f = 50Hz时

剩余磁感应强度为:

$$B_r = \frac{R_2 C}{N_2 S} u_r = 0.0941 T$$

矫顽力为:

$$H_C = \frac{N_1}{lR_1} u_C = 9.81 A/m$$

误差计算公式:

$$\frac{\sigma_{B_r}}{B_r} = \frac{\sigma_{u_r}}{u_r}$$

测量误差:  $\sigma_{u_{r}1} = 2\% \times 3.5 + 0.3\% \times 5 \times 8 = 0.19$ mV

读数误差:  $\sigma_{u_{r^2}} = 0.05 mV$ 

误差合成: 
$$\sigma_{\mathbf{u_r}} = \sqrt{\sigma_{\mathbf{u_r}1}^2 + \sigma_{u_r2}^2} = 0.2 \text{mV}$$

故:

$$\sigma_{B_r} = 0.005T$$

$$B_r = 0.094 \pm 0.005$$
T

同理矫顽力的误差:

$$\frac{\sigma_{H_C}}{H_C} = \frac{\sigma_{u_C}}{u_C}$$

测量误差:  $\sigma_{u_r1} = 2\% \times 17 + 0.3\% \times 100 \times 10 = 3.3 \text{mV}$ 

读数误差:  $\sigma_{u_r2} = 1mV$ 

误差合成: 
$$\sigma_{\mathbf{u_r}} = \sqrt{\sigma_{\mathbf{u_r}1}^2 + \sigma_{\mathbf{u_r}2}^2} = 3.4 \text{mV}$$

故:

$$\sigma_{H_C} = 2.0 \text{A/m}$$

$$H_C = 9.8 \pm 2.0 \text{A/m}$$

#### 1.2.2 取f = 150Hz时

剩余磁感应强度为:

$$B_r = \frac{R_2 C}{N_2 S} u_r = 0.105 T$$

矫顽力为:

$$H_C = \frac{N_1}{lR_1} u_C = 11.5 A/m$$

误差计算公式:

$$\frac{\sigma_{B_r}}{B_r} = \frac{\sigma_{u_r}}{u_r}$$

测量误差:  $\sigma_{u_r 1} = 2\% \times 3.9 + 0.3\% \times 5 \times 8 = 0.20$ mV

读数误差:  $\sigma_{u_{r^2}} = 0.05 mV$ 

误差合成: 
$$\sigma_{\mathbf{u_r}} = \sqrt{\sigma_{\mathbf{u_r}1}^2 + \sigma_{u_r2}^2} = 0.21 \text{mV}$$

故:

$$\sigma_{B_r} = 0.006$$
T

$$B_r = 0.105 \pm 0.006$$
T

同理矫顽力的误差:

$$\frac{\sigma_{H_C}}{H_C} = \frac{\sigma_{u_C}}{u_C}$$

测量误差:  $\sigma_{u_r 1} = 2\% \times 20 + 0.3\% \times 100 \times 10 = 3.4 \text{mV}$ 

读数误差:  $\sigma_{ur2} = 1mV$ 

误差合成: 
$$\sigma_{\mathbf{u_r}} = \sqrt{\sigma_{\mathbf{u_r}1}^2 + \sigma_{u_r2}^2} = 3.5 \text{mV}$$

故:

$$\sigma_{H_C} = 2.1 \text{A/m}$$


$$H_C = 11.5 \pm 2.1 \text{A/m}$$

#### 1.3 不同时间常数下的李萨如图

\*取定:  $I_m = 0.2A$ .


### 1. 3. 1 取 $R_2C = 0.01$ s时

图 2 取 $R_2C = 0.01$ s的李萨如图




### 1. 3. 2 取 $R_2C = 0.05$ s时

图 3 取 $R_2C = 0.05$ s的李萨如图



### 1. 3. 3 取 $R_2C = 0.5$ s时

图 4 取
$$R_2C = 0.5$$
s的李萨如图



### 2 样品 1 基本磁化曲线

各元件参数取为:

$$R_1 = 2\Omega, R_2 = 50 \text{k}\Omega, C = 10.0 \mu\text{F}, f = 100 \text{Hz}$$

#### 2.1 测量数据

电路图及各物理量命名同教材图 30-3


表 2 动态磁化曲线数据

	农 2				
$u_{\rm x}/{\rm mV}$	u <sub>y</sub> /mV	H/(A/m)	B/T		
0	0	0	0		
9	0.8	5.19	0.0215		
18	1.8	10.4	0.0484		
29.5	3.1	17.0	0.0833		
40.5	4.35	23.4	0.117		
48	5.45	27.7	0.147		
60	6.77	34.6	0.182		
70	7.87	40.4	0.212		
80.1	8.92	46.2	0.240		
90	9.65	51.9	0.259		
101	10.33	58.3	0.278		
110	10.85	63.5	0.292		
120	11.37	69.2	0.306		
131	11.85	75.6	0.319		
142	12.20	81.9	0.328		
162	12.77	93.5	0.343		
173	13.00	99.8	0.349		
182	13.15	105	0.353		
190	13.27	110	0.357		
203	13.52	117	0.363		
212	13.60	122	0.366		
223	13.77	129	0.370		

232	13.82	134	0.372
258	14.10	149	0.379
295	14.35	170	0.386
372	14.72	215	0.396


绘图如图 5 所示:

图 5 动态磁化曲线



# 2.2 $\mu_m$ 随H变化关系

利用表 2 数据计算 $\mu_m$ 随H变化关系如图 6 所示: 图 6  $\mu_m$ 随H变化关系



# 3 样品 1 在不同直流 H 下的可逆磁导率μ<sub>r</sub>

\*样品 1 的起始磁导率 $\mu_i$ 看作在H = 0时的 $\mu_r$ . 各元件参数取为:

$$R_1 = 2\Omega, R_2 = 20 \text{k}\Omega, C = 2.0 \mu\text{F}, f = 100 \text{Hz}$$


#### 3.1 测量数据

记线圈 3 内电流强度为I,  $u_1$ ,  $u_2$ 定义同上。

表 3 可逆磁导率与I关系测量数据

I/A	$u_{\rm x}/{ m mV}$	u <sub>y</sub> /mV
0.00	7.50	7.10
0.01	5.75	4.10
0.02	7.50	4.25
0.03	9.60	4.35
0.04	12.85	4.40
0.05	15.70	4.20
0.06	17.90	3.75
0.07	18.85	3.18
0.08	19.10	2.65
0.09	19.00	2.30
0.10	18.60	1.93

图 7 可逆磁导率μ<sub>r</sub>与I关系



# 4 样品 $2 在 H_m = 400 A/m$ 下的磁滞回线

各元件参数取为:

 $R_1=2\Omega, R_2=50 \mathrm{k}\Omega, C=10.0 \mu \mathrm{F}$  测得数据为:


表 4 样品 2 测试数据

f/Hz	$u_{2m}/\text{mV}$	$u_{2r}/\mathrm{mV}$	$u_{1C}/\mathrm{mV}$
20	25.0	17.0	86
40	24.6	18.6	101
60	24.4	18.0	115

代入公式计算得:

表 5 样品 2 参数随频率变化关系

f/Hz	$B_m/\mathrm{T}$	$B_r/T$	$H_C/(A/m)$
20	0.694	0.472	86
40	0.683	0.517	101
60	0.678	0.500	115



姓名	2号	星期第二组	页码 /
2. R1 = \$2.52 R2.50	KD C=10.0 pF f=1	130 Hz.	
动态流流电影			
Hm - U, /mV	0 9 18 29.5	40.5 48 60. 70	
Bm - U2/mV	THE RESIDENCE OF THE PARTY OF T	435 \$45 677 7.87.	
U. /mV	80.1 90 600	1/0 120 131 142 152 10.85. 11.37 11.85 12.2 13.52	
U> (MV			
U. /mV		190. 203 212 223	
Uz/mV	12.77 13.00 . 13.15	13.27. 13.52 13.60 10 13.77	
U./mV	232 258 0	295 372	
N2/mV	13.82 14.10. 1	4.35 1472.	
3. 样况 1. 更起於	磁导率 以 市 石面直流	H下河遊7為导率 Mr	
n: \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	R2=20KR2 C=2-0/MF. 7.5mV += 7.1mV	J>(0) TE.	
to M:			
电流 I/A · 0.0 0·	0.020 0,030. 0,040.	0,050 0,060.	
441/mV 5.75	7.50. 9.60. 12.85	15.70. 17.90.	
AN2/mV 4.10.	4.25. 4.35. 4.40	4.50 - 3.75	
東流 1/4 0.070.	0.080. 0.090	0.100	
AU1 /mV 18.85	192 19.10 19.00	18.6.	
ΔU2/mV 3.18	2.65 2.70	1.93	

姓名	路 学号 >>mo11444		星期 - 第 丁 组	页码 02/
Y, f = 20 Mz.	lam Bm = 25 m V Br	U2r = 17.0 mV	U1c = 86.0 mV.	
f = 40Hz .	U2m > 24.6 mV	Ur = 18.6mv.	Me = 101.0 mV	
f= botta.	Usm = >4.4mV 1	Var = 18,0mV.		
			- The	5.16